ODOURVAC TOILET VENTILATION

INSTALLATION & MAINTENANCE INSTRUCTIONS

FANTECHTRADE
MADE FOR TRADE

OVK2 – ODOURVAC ADD ON KIT

PACKAGE CONTENTS

1x Ø150-Ø150-Ø50mm Boss Junction

1x Ø50mm socket

1x Ø50mm to Ø40mm reducer

1x 1 x 250mm length of 40mm PVC pipe

1x 200mm length of 40mm clear flexible

2x 100mm length of 40mm PVC pipe

1x Ø40mm x 90° elbow

2x 40mm cover plate

1x Balancing valve

NOT INCLUDED

- One of the following Fantech Plus ducted fan kits:
  - **Ducted In-line** – Model ILK150 or ILK150HP
  - **Ducted Through Roof** - Combination of Ezifit Thru Roof Fan (ECE152 or ECE154), Flexible duct (DUCT150-6MPK), Ceiling Mounted Grille (RCG150 or RCG200-150)
  - **Ducted Through Wall** - Combination of Ezifit Thru Wall Fan model (EWE152 or EWE154), Flexible duct (DUCT150-6MPK), Ceiling Mounted Grille (RCG150 or RCG200-150)
  - **Ducted In-Wall** - Combination of Ezifit In-Wall Fan model (EIE150), Flexible duct (DUCT150-6MPK), Ceiling Mounted Grille (RCG150 or RCG200-150)
- 50mm PVC pipe, enough to extend from roof cavity to the toilet position.
- Extra bends if required
- Pipe brackets & fittings
- PVC glue
- Duct Tape

POWER SUPPLY

GPO power point source installed by a licensed electrician where the fan will be located.

The fan can be activated by any of the following options: connecting to light switch, separate fan switch, or movement sensor switch. This work must also be completed by a licensed electrician.

THE ODOURVAC SYSTEM

The OdourVac system connects directly into the back of the cistern and draws odours from the toilet pan via the internal overflow pipe. For this to occur it is essential that a hole (if one does not already exist) be drilled into the back of the cistern to enable the OdourVac connection. If your selected toilet suite does not have an additional hole, please refer to Step 2a for information on Cistern drilling.

COMPATIBILITY

The OdourVac system works with most toilet suites. However, there are certain brands/models on the market which DO NOT enable air to be drawn from the pan, which will mean the OdourVac system will not work.

FANTECHTRADE
MADE FOR TRADE

INSTALLATION

⚠Warning:

Installation of this product should be carried out by appropriately qualified persons


There are 2 stages when installing the OVK1:

Rough In – The project is at lock up stage and prior to the plaster going on the walls. It's at this stage that the fan, ductwork pipe, and bends are installed.

Fit Off – Once the plaster/painting/tiling has been completed and the plumber is commencing the toilet fit-off, the OdourVac system can be fitted off.

ROUGH IN

1. FAN AND DUCTWORK PIPE INSTALLATION




1a) Determine the intended route of the flexible ductwork in the ceiling space. Ensure the location and type of toilet suite is known and where the OdourVac hole will be located in the cistern.

1b) Install flexible duct and fan according to the separate instructions with that fan. Ensure that the flexible duct work runs as close as possible to the location of the toilet in the roof space.

1c) Cut the flexible duct near the toilet location and join it to either side of the Ø150mm boss junction using duct tape. Ensure the Ø50mm section of the boss junction is facing down the wall cavity, in-line with the position of the cistern. If this is not possible, use a combination of additional elbows and 50mm pipe to reach the cavity.

2. WALL CAVITY DUCTWORK AND TOILET (WC) CONNECTION PREPARATION



2a) Drill a 50mm hole in the back of the cistern (if it doesn't already exist) at required location using a diamond hole saw (these can be purchased at most hardware stores). To do this, check toilet dimensions and measure point to centre of OdourVac hole. The 50mm OdourVac hole should be either to left or right from centre of cistern and about 10mm from the top. Also measure height from floor level to the centre of the hole. Don't forget to include the thickness of the floor bed and tiles. This is the reference point to which you rough in ductwork pipe in wall cavity. **If toilet is not on site at rough in, you must find out toilet being installed and intended position of OdourVac hole.**

2b) From the boss junction connection, connect and continue the 50mm PVC pipe down wall cavity. (If ductwork pipe needs to be chased into brick or masonry walls, 40mm pipe may be used for full length of wall cavity)

2c) Connect 50mm socket to pipe and insert 40mm reducer into socket. Attach 250mm length 40mm pipe to reducer, then 40mm clear flexible ducting to PVC pipe. Glue all PVC fittings. Connect clear flex to PVC using duct tape. The clear flex assists in final fit off and provides flexibility/movement in event that the fit off measurements are slightly out.

2d) Attach short length of 40mm pipe to bottom of the clear flex with duct tape. Attach/glue 40mm 90° PVC bend to pipe.

2e) The bend must terminate at the height and location of the future OdourVac hole in cistern (refer Step 2a). Bend must face where the hole will be in cistern. Leave ductwork pipe in wall cavity to be sheeted over. Take measurements as to location of bend in cavity for fit off in later steps.

FIT OFF

3. WC CONNECTION FIT OFF

3a) Once installation of toilet pan is complete, position cistern in its permanent location and mark the 50mm OdourVac hole location on wall or use dimensions to locate (Step 2e). Remove and cut hole in plaster or tiles.

3b) Locate 40mm bend in wall cavity and glue final short length 40mm PVC pipe to bend. Slide 40mm cover plate over 40mm PVC pipe and glue to wall to cover any excess hole in wall. This pipe will be trimmed/adjusted after connecting cistern and installing the balancing valve.

3c) Feed pipe through hole in cistern and re-attach cistern to pan. Trim 40mm inlet pipe approx flush with inside of cistern. Slide other 40mm cover plate over PVC pipe and glue cover plate to inside of cistern. The top of both cover plates may need to be trimmed so that they cannot be seen once cistern lid is in place.

3d) Attach OdourVac Balancing Valve by pushing into pipe. The soft foam gasket will seal any other gaps. Once installed, seal any gaps with silicone to reduce air leaks, as they may affect air performance.

3e) Complete any remaining installation of internal and external grilles as per the provided (separate) instructions.

3f) To achieve good performance ensure power is supplied to exhaust fan then open balancing valve totally and adjust to achieve desired airflow.

OdourVac is a registered trade mark of OdourVac Ventilation Systems Pty. Ltd.

WARRANTY

Scan the above QR code or visit
www.fantech.com.au/warranty
to view WARRANTY
information online

FANTECHTRADE
MADE FOR TRADE

www.fantechtrade.com.au
www.fantechtrade.co.nz

info@fantechtrade.com.au

Australia: 1300 387 587
New Zealand: 0800 106 266